

Instructions Manual

Widen

WKLO05T

Magnifying Lamp

VERSION 1.26

Fire Warning:

Never leave magnifying lenses in direct sunlight or in any location that might come into contact with direct sunlight. This will cause a fire.

How to install:

1. Clamping version:

Clamp the bracket to the edge of any horizontal surface of the bench or other place you want. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

2. Floor version:

Put the floor stand on the horizontal ground. Insert the bottom stem of the arm into the hole on the top of the floor stand. Plug in the magnifier lamp.

Light control:



- Turn on/off the light.



- Adjust the light LED temperature in 3500K/5000K/6500K



- To adjust the light darker (4 levels)



- To adjust the light brighter (4 levels)

The lamp turn off, the status will be saved in memory.

Lamp cover control:

The lamp cover still can turn on/off the lamp. When the lamp is powered on and in standby mode, open the lamp cover, the light is on; close the cover, it is off.

This function coexists with the aforementioned switch and also in memory.

Important! Safety instructions:

1. Indoor use only.
2. Environment temperature -5°C-40°C.
3. Humidity: ≤95%.
4. Never disassemble the lamp by yourself,
5. Plug must be taken out while repairing the light.

If the external flexible cable or cord of this light is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard..

WK

Imported by
WEEKKO BARCELONA SL

Pol. Ind. La Valldan
Camí de Garreta, 92
08600 Berga
Barcelona - Spain
T. +34 93 824 90 20
E. info@weelko.com